



For Models: KERS205TWH2, KERS205TBL2, KERS205TSS2, KERS205TBT2
(White) (Black) (S.Steel) (Biscuit)




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1		Literature Parts
	W10168033	Use & Care Guide
	W10167997	Wiring Diagram
	W10185365	Installation Instructions
2		Cooktop
	W10160619	White
	W10160621	Black
	W10160620	Biscuit
3	8010P149-60	Spacer Snap-In (4)
4	7406P365-60	Element LF/RR (2)
5	9762851	Element, Warm
6	7803P087-60	Spring, Element
7	3196165	Screw
8	4011F497-51	Bottom, Burner Box
9	4453909	Element LR/RF (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KERS205TWH2, KERS205TBL2, KERS205TSS2, KERS205TBT2
(White) (Black) (S.Steel) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3196068	Lens
2		Panel, Backguard & Switch Assy
	W10182778	Black
	W10182780	White
	W10183576	Biscuit
	W10182779	Stainless Steel
3	7101P309-60	Screw, Switch (10)
4		Switch, Infinte
	7450P011-60	Dual RF/LR (2)
	7403P373-60	LF/RR (2)
	7403P877-60	Low Heat
5	3801F945-51	Bracket, Control
6	8507P331-60	Control


Illus. No.	Part No.	DESCRIPTION
7		End Cap, Left
	3807F703-70	Black
	3807F703-71	White
	3807F703-78	Biscuit
8	3196178	Screw
9		Shield, Heat Visor
	3604F382-09	Black
	3604F382-81	White
	3604F382-88	Biscuit
10	3604F381-19	Shield, Vent
12	4005F804-51	Cover, Rear Wire

Illus. No.	Part No.	DESCRIPTION
13		End Cap, Right
	3807F702-70	Black
	3807F702-71	White
	3807F702-78	Biscuit
14	7101P376-60	Screw
15	3196178	Screw
16	7407P136-60	Light, Indicator
17		Knob (4)
	W10160370	Black
	W10160371	S.Steel
	W10160368	White
	W10160369	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: KERS205TWH2, KERS205TBL2, KERS205TSS2, KERS205TBT2
(White) (Black) (S.Steel) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Models: KERS205TWH2, KERS205TBL2, KERS205TSS2, KERS205TBT2
(White) (Black) (S.Steel) (Biscuit)


Illus. No.	Part No.	DESCRIPTION
1	2618F172-58	Panel, Side White
	2618F172-69	Black
	2618F172-57	Biscuit
2	3196165	Screw
3	3804F311-51	Retainer, Side
4	8002P104-60	Latch Assembly
5	4002P347-51	Main Back
6	4005F754-51	Cover, Main Wire
7	4005F712-51	Bottom Wire Cover
8	3196178	Screw
9	7003P145-60	Insulator, Cord
10	4005P703-51	Cover, Wire (LWR)
11	4005P704-51	Panel, Access
12	7103P027-60	Nut, Term.Block
13	7401P039-60	Block, Terminal
14	3605F146-51	Plate, Conduit
20	7101P507-60	Leg, Leveling
21	3801F656-51	Bracket, Anti-Tip
22	7101P485-60	Screw, Anti-Tip
23	3604F371-51	Shield, Heat
24	7101P376-60	Screw, 8AB 1/2 (4)
25	7406P493-60	Element, Broil
26	7430P042-60	Sensor, Oven
27	8026P081-60	Vent, Oven
28	898020-001	Lens, Bulb
29	7101P282-60	Screw (4)
30	7101P618-60	Screw, Shoulder(6)
31	W10162385	Gasket
32	8010P148-60	Spacer, Side Pnl.
33	7106P125-60	Receiver, Hinge
34	7407P181-60	Light Assembly
36	7101P375-60	Screw (Black) (2)
38	7407P103-60	Bulb, Oven
39	7101P500-60	Screw, Shoulder
40	3801P822-45	Support, Ov BTM
41	7406P451-60	Element, Bake
42	3807P680-45	Support, Oven
43	2205F053-19	Bottom, Oven
44	3401F084-45	Pan, Bake Brnr
45	7403P857-60	Switch, Terminal
46	7101P336-60	Screw (2)

INSULATION

7002P362-60	Insulation, Wrap
7002P492-60	Insulation, Back
3804F316-51	Retainer, Insulation

DOOR PARTS

For Models: KERS205TWH2, KERS205TBL2, KERS205TSS2, KERS205TBT2
(White) (Black) (S.Steel) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
1	3608F139-70	Black
	3608F139-71	White
	3608F139-78	Biscuit
2	W10169552	Black
	W10169553	White
	W10169554	Biscuit
3	7106P124-60	Hinge, Door (2)
4	3601F380-51	Baffel, Retainer
5	7101P376-60	Screw (6)
6	7902P436-60	Glass, Inner (2)
7	3801F886-51	Frame, Glass Inner
9	W10176584	Screw
10	2402W297-19	Lining, Door
11	3801F886-51	Bracket, Glass (2)
12	7002P246-60	Insulation, Door


Illus. No.	Part No.	DESCRIPTION
13	7101P427-60	Screw (8)
14	3801P858-45	Left
	3801P857-45	Right
15	w10208308	Tape, White
16	3608F126-70	Black
	3608F126-71	White
	3608F126-78	Biscuit
17	8270P194-60	White
	8270P193-60	Black
	8270P194-60	Biscuit
18	3608F092-71	White
	3804F236-51	Black
	3608F092-78	Biscuit

Illus. No.	Part No.	DESCRIPTION
19	7101P282-60	Screw 10-24x5/16
20	w10160906	White
	W10182773	Black
	W10183574	Biscuit
		(Order Item #15 When Replacing Door Glass)
21	W10153013	White
	W10153016	S.Steel
	W10153015	Black
	W10153014	Biscuit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DRAWER AND RACK PARTS

For Models: KERS205TWH2, KERS205TBL2, KERS205TSS2, KERS205TBT2
(White) (Black) (S.Steel) (Biscuit)



Illus. No.	Part No.	DESCRIPTION
2	3196165	Screw (2)
3	3405F037-80	Drawer, Storage
4	7103P082-60	Nut, Lock
5	8010P130-60	Spacer, Rubber
6	7118P032-60	Shaft, Roller
7	3196165	Screw
8	7103P082-60	Nut
9		Panel, Drawer
	W10163040	White
	W10163038	Black
	W10163041	Biscuit
10	3406P034-51	Runner, Drawer
11	7103P190-60	Nut, Lock
12	8014P022-60	Roller, Drawer
13	7118P032-60	Shaft, Roller
14	8038P037-60	Stop, Drawer
15	w10179196	Rack, Oven

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: KERS205TWH2, KERS205TBL2, KERS205TSS2, KERS205TBT2
(White) (Black) (S.Steel) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)			<u>PAINT, TOUCH-UP (1/2oz.)</u>			<u>ACCESSORY PARTS</u>		
<u>REFINISHING MATERIAL</u>			72017 White			241430 Foil, Aluminum		
799832 Kit, Porcelain			4392899 Biscuit			Oven (18" x 25')		
242756 Touch-Up			511873 White Porcelain			3191048 Cleaner, Glass		
261582 Grease			(2 Oz.)			<u>WIRING HARNESS PARTS</u>		
<u>INSULATION</u>			<u>PAINT, PRESSURIZED SPRAY</u>			5171P792-60 Harness, Wire		
261514 Insulation,			<u>(12 oz.)</u>			(Cooktop Right)		
Fiberglass (1-1/2"			350930 White			5171P791-60 Harness, Wire		
x 24" x 120")			4392901 Biscuit			(Cooktop Left)		
240132 Insulation,			285006 Superior Black			W10167991 Harness, Wire		
Fiberglass (2-1/2"			206922 Primer (White)			(Burner Box)		
x 22" x 120")			<u>PAINT, BULK (1 qt.)</u>			W10160683 Harness, Wire		
			799344 White (Uncut)			(Main)		
			4392900 Biscuit(Uncut)			8019P013-60 Clip, Wire		
						7101P027-60 Screw, Ground		

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST